

DMX Charts Porgy & Bess 2018

DMX Smartfade

Gerät	Patch	Fuse	Dim	Start	DMX	Func.
Stufe 1 Front L	P4.1		1	1	A1	dim
Stufe 2 Front LM	P4.2		2	2	A2	dim
Stufe 3 Front RM	P4.3		3	3	A3	dim
Stufe 4 Front R	P4.4		4	4	A4	dim
Stufe 5 Bühne	P5.1		5	5	A5	dim
Stufe 6 Bühne	P5.2		6	6	A6	dim
Stufe 7 Bühne	B1.1		7	7	A7	dim
Stufe 8 Bühne	B1.2		8	8	A8	dim
Stufe 9 Bühne	B2.1		9	9	A9	dim
Stufe 10 Bühne	B2.2		10	10	A10	dim
PAR64	P2.1		11	11	A11	dim
Hauslicht			12	12	A12	dim
Worklight	B3.1		13	13	A13	dim
Spare Dimmer1			14	14	A14	dim
Spare Dimmer2			15	15	A15	dim
Spare Dimmer3			16	16	A16	dim
Spare Dimmer4			17	17	A17	dim
Spare Dimmer5			18	18	A18	dim
Power Spot 9 Q5 4Stk B3	B3.2	Fix1		19	A19	Rot
					A20	Grün
					A21	Blau
					A22	Weiß
					A23	Amber
					A24	Dim
Power Spot 9 Q5 4Stk B3	B3.2	Fix1		26	A26	Rot
					A27	Grün
					A28	Blau
					A29	Weiß
					A30	Amber
					A31	Dim
Power Spot 9 Q5 2Stk B3	B3.2	Fix1		33	A33	Rot
					A34	Grün
					A35	Blau
					A36	Weiß
					A37	Amber
					A38	Dim
		A39	Strobe			

Gerät	Patch	Fuse	Dim	Start	DMX	Func.
Power Spot 9 Q5 4Stk B2	B2.3	Fix1		40	A40	Rot
					A41	Grün
					A42	Blau
					A43	Weiß
					A44	Amber
					A45	Dim
					A46	Strobe
Leer					A47	-
Leer					A48	-
Power Spot 9 Q5 4Stk B2	B2.3	Fix1		49	A49	Rot
					A50	Grün
					A51	Blau
					A52	Weiß
					A53	Amber
					A54	Dim
					A55	Strobe
Leer					A56	
Power Spot9 Q5 1Stk Schildbel.	B1.3	Fix1		57	A57	Rot
					A58	Grün
					A59	Blau
					A60	Weiß
					A61	Amber
					A62	Dim
					A63	Strobe
Leer					A64	
Leer					A65	
TriPanel Publ. 3Stk P4, 2Stk P3, 3Stk P2, 1Stk P1	P4.5,P2.2 P3.1,P1.1	Fix2		66	A66	Rot
					A67	Grün
					A68	Blau
TriPanel Gal. 2Stk P4, 2 Stk P3, 2Stk P2, 2Stk P1	P4.5,P3.1 P2.2,P1.1	Fix2		69	A69	Rot
					A70	Grün
					A71	Blau
PAR56 LED Säulen	-	-		72	A72	Rot
					A73	Grün
					A74	Blau
					A75	Full colour
					A76	Strobe/Speed
					A77	Modi
Led Balken 50cm Curtain	B3.3	Fix3		78	A78	Rot
					A79	Grün
					A80	Blau

DMX **B** Stairville DMX Master 1

Gerät	Patch	Fuse	Start	DMX	Func.
Remotebügel 1	P4.6	Fix4	1	B1	Pan left
				B2	Pan right
				B3	Tilt up
				B4	Tilt down
				B5	Focus smaller
				B6	Focus larger
Remotebügel2	P4.6	Fix4	17	B17	Pan left
				B18	Pan right
				B19	Tilt up
				B20	Tilt down
				B21	Focus smaller
				B22	Focus larger
Remotebügel3	P4.6	Fix4	33	B33	Pan left
				B34	Pan right
				B35	Tilt up
				B36	Tilt down
				B37	Focus smaller
				B38	Focus larger
Remotebügel4	P4.6	Fix4	49	B49	Pan left
				B50	Pan right
				B51	Tilt up
				B52	Tilt down
				B53	Focus smaller
				B54	Focus larger
Phantom50 LED Links	B3.5	Fix5	65	B65	Pan
				B66	Tilt
				B67	Pan fine
				B68	Tilt fine
				B69	Pan/Tilt Speed
				B70	Colourwheel
				B71	Shutter
				B72	Dimmer
				B73	Gobo
				B74	Rotation
				B75	Prisma
				B76	Funktion
				B77	Built in Prg.

Gerät	Patch	Fuse	Start	DMX	Func.
Phantom50 LED Links Mitte	B3.4	Fix5	81	B81	Pan
				B82	Tilt
				B83	Pan fine
				B84	Tilt fine
				B85	Pan/Tilt Speed
				B86	Colourwheel
				B87	Shutter
				B88	Dimmer
				B89	Gobo
				B90	Rotation
				B91	Prisma
				B92	Funktion
				B93	Built in Prg.
Phantom50 LED Rechts Mitte	B3.4	Fix5	97	B97	Pan
				B98	Tilt
				B99	Pan fine
				B100	Tilt fine
				B101	Pan/Tilt Speed
				B102	Colourwheel
				B103	Shutter
				B104	Dimmer
				B105	Gobo
				B106	Rotation
				B107	Prisma
				B108	Funktion
B109	Built in Prg.				
Phantom50 LED Rechts	B3.4	Fix5	113	B113	Pan
				B114	Tilt
				B115	Pan fine
				B116	Tilt fine
				B117	Pan/Tilt Speed
				B118	Colourwheel
				B119	Shutter
				B120	Dimmer
				B121	Gobo
				B122	Rotation
				B123	Prisma
				B124	Funktion
B125	Built in Prg.				